






# Reinforcement of Leather Goods

Tapes, sheets and die-cut spots for areas which need a special reinforcement

[Link](#)

Article no.	Photo	Composition / Description	Width / make-up	Technical data Breaking load/extens. at break (at 25 mm) - Thickness	Coating options PS = Pressure sensitive HS = Heat sensitive 1/2 = Primer coating
1750		High-tenacity Nylon very strong	3 - 1000 mm sheets	930 N 22% 0.24 mm	1750 = 1 x PS 1752 = 1 X HS 1753 = 2 x HS 1755 = 2 x PS 1756 = 1 x PS, 1/2 x HS 1759 = 1 x PS, 1 x HS 27725 = 1 x PS stiff finish 27719 = 2 x 1/2 HS (PU)
1756		High-tenacity Nylon very strong	3 - 1000 mm sheets	930 N 22% 0.24 mm	1 x PS, 1/2 x HS
1950		Polyester Non-woven fine and soft	sheets	102 N 33% 0.26 mm	1950 = 1 x PS 1952 = 1 x HS 1953 = 2 x HS 1955 = 2 x PS 1956 = 1 x PS, 1/2 x HS 1959 = 1 x PS, 1 x HS
57507		Polyamide woven reinforcing tape	3 - 60 mm	12 mm = 720 N 30 mm = 1800 N 25%, 0.30 mm	57507 = 1 x PS, 1 x Latex Vulk.
Spots		Pre die-cut reinforcing spots	in many different shapes (also to customers' designs)		